

Ninebot Max part number list

- 14.02.0192.20; Ninebot MAX G30 Electric Scooter Battery
- 14.01.0381.00; Ninebot MAX G30 Electric Scooter Front Bumper Strip (Inc Left & Right)
- 14.01.0382.00; Ninebot MAX G30 Rear Bumper Strip Assembly (Inc Left & Right)
- 14.02.0195.00; Ninebot MAX G30 Charging Port Base Assembly
- 14.01.0383.00; Ninebot MAX G30 Rear Mud Guard
- 14.01.0384.00; Ninebot MAX G30 Folding Hook
- 14.02.0196.00; Ninebot MAX G30 Electric Scooter Wheel Hub Motor
- 14.02.0197.00; Ninebot MAX G30 Rear Tail Light
- 14.02.0198.00; Ninebot MAX G30 Control Board Assembly
- 14.02.0311.00; Ninebot MAX G30D Control Board Assembly
- 14.02.0199.00; Ninebot MAX G30 Built-In Charger
- 14.01.0385.00; Ninebot MAX G30 Battery Compartment Cover Assembly
- 14.01.0386.00; Ninebot MAX G30 Front Reflective Sticker
- 14.01.0387.00; Ninebot MAX G30 Front Fork Cover (Left)
- 14.01.0388.00; Ninebot MAX G30 Front Fork Cover (Right)
- 14.01.0389.00; Ninebot MAX G30 Stand Pipe Compartment
- 14.01.0390.00; Ninebot MAX G30 Limit Ring
- 14.01.0391.00; Ninebot MAX G30 Rear Reflective Sticker
- 14.01.0392.00; Ninebot MAX G30 Rear Fork Decorative Cover
- 14.01.0427.00; Ninebot MAX G30 Air Nozzle
- 14.01.0393.00; Ninebot MAX G30 Stand Pipe Double Wire Plug
- 14.01.0394.00; Ninebot MAX G30 Stand Pipe Brake Wire Plug
- 14.01.0395.00; Ninebot MAX G30 Inclined Tube Wire Plug
- 14.01.0396.00; Ninebot MAX G30 Brake Wire Set
- 14.01.0397.00; Ninebot MAX G30 Front Fork Assembly
- 14.01.0398.00; Ninebot MAX G30 Main Control Cable
- 14.01.0399.00; Ninebot MAX G30 Front Mud Guard (Fender)
- 14.01.0400.00; Ninebot MAX G30 Front Wheel Assembly
- 14.01.0401.00; Ninebot MAX G30 Front Fork Front Pipe Rotating Part

14.01.0402.00; Ninebot MAX G30 Drum Brake

14.01.0403.00; Ninebot MAX G30 Handle Grip

14.01.0405.00; Ninebot MAX G30 Bell

14.01.0407.00; Ninebot MAX G30 Deck Assembly

14.01.0408.00; Ninebot MAX G30 Max Kick Stand

14.01.0409.00; Ninebot MAX G30 Foot Mat Assembly

14.02.0203.00; Ninebot MAX G30 AC Power Cable (Europe Standard)

14.01.0411.00; Ninebot MAX G30 Front Fork (Left & Right) Screw Plug Cover

14.02.0200.00; Ninebot MAX G30 Dashboard Assembly

14.02.0201.00; Ninebot MAX G30 Head Light Assembly

14.01.0412.00; Ninebot MAX G30 Hanger Assembly

10.02.5019.00; Ninebot MAX G30 Brake Handle Assembly

14.02.0202.00; Ninebot MAX G30 Electric Throttle Assembly

14.02.0313.00; Ninebot MAX G30D Brake Lever Assembly

14.01.0413.00; Ninebot MAX G30 Dashboard Cover Component

14.01.0414.00; Ninebot MAX G30 Logo

14.01.0415.00; Ninebot MAX G30 Handle Bar Wire Plug (Left)

14.01.0416.00; Ninebot MAX G30 Stem Assembly Gasket

14.01.0417.00; Ninebot MAX G30 Stem Assembly Screw Hole Plug

14.01.0418.00; Ninebot MAX G30 Handle Bar Pipe

14.01.0428.00; Ninebot MAX G30 Wire Harness

14.01.0419.00; Ninebot MAX G30 Main Stem Assembly

14.01.0420.00; Ninebot MAX G30 Handle Bar Locking Piece

14.01.0421.00; Ninebot MAX G30 Head Light Fixing Piece

14.01.0422.00; Ninebot MAX G30 Front Bushing

14.01.0424.00; Ninebot MAX G30 Front Tyre

14.01.0425.00; Inner Hexagon Semicircular Head Carbon Steel Galvanized Screw_M5*12

14.01.0426.00; Inner Hexagon Socket Head Carbon Steel Wpring Washer Combination Screw_M6*25

14.01.0283.00; Inner Hexagonal Cylindrical Head anti-Carbon Steel Screw_M5*20

14.01.0089.00; Cross Recessed Countersunk With Blue & White Zinc Screws_M4*8

10.01.5070.00; Cross Semicircular Head Carbon Steel Galvanized Screw M2*5

14.01.0285.00; Inner Hexagonal Cylindrical Head anti-Carbon Steel Screw_M3*10

10.01.5073.00; Inner Hexagon Socket Head Carbon Steel Spring Washer Combination Screw_M6*30

14.01.0301.00; Inner Hexagon Socket head White Blue Zinc Screws_M4*8

14.01.0305.00; Hexagon Flange Floral Nut_M10

10.01.5057.00; Cross Semicircular Head Flat Tail Self-Tapping Carbon Steel Galvanized Screw_ST2.9*69.5

10.01.1081.00; Cross Semicircular Head Flat Tail Self-Tapping Carbon Steel Galvanized Screw

14.01.0313.00; Cross Semicircular Head Flat Tail Self-Tapping Carbon Steel Galvanized Screw_ST2.9*9.5

14.01.0348.00; Hexagon Socket Head Black Zinc Screw_M3*10

14.01.0349.00; Hexagon Socket Head Black Zinc Screw_M3*6

14.01.0314.00; Inner Hexagon Socket Head Flat Washer With Blue and White Zinc Combination Screw_M4*12

14.01.0286.00; Inner Hexagon Socket head White Blue Zinc Screws_M4*12

14.01.0352.00; Inner Hexagon Flower-Shaped Countersunk Head F-Type Self-Tapping Screw_ST2.9*9.5

14.01.0351.00; Inner Hexagon Socket Head with Blue and White Zinc Three Combination Screws_M4*8

14.01.0353.00; Inner Hexagonal Flower-Shaped Pan Head Screw_M4*8

14.01.0317.00; Inner Hexagon Socket Head with Blue and White Zinc Three Combination Screws_M4*10

14.01.0329.00; Inner Hexagon Socket Head Bolt Plating Blue & White Zinc Combination Screw_M4*10

14.01.0319.00; Inner Hexagon Socket Head Flat Washer With Blue and White Zinc Combination Screw_M4*16

14.01.0347.00; Battery Compartment Cover Security Screws

10.01.5128.00; Hexagon socket galvanized steel screw with countersunk head-M5*16

10.01.5066.00; Galvanized carbon steel screw with hexagonal socket head-M4*6

14.01.0328.00; Inner Hexagon Flower Shaped Pan Head Carbon Steel Screw_M6*14

14.01.0306.00; Hexagon Flange Floral Nut_M7

04.01.0259.00; Ninebot MAX G30 Inclined Tube Waterproof Plug

04.09.0022.00; Ninebot MAX G30 Rear Light Wire

04.01.0274.00; Ninebot MAX G30 Line pressing foam

04.01.0276.00; Ninebot MAX G30 Tube Upper Head Waterproof Plug (Large)

04.01.0277.00; Ninebot MAX G30 Tube Upper Head Waterproof Plug (Small)

04.01.0282.00; Ninebot MAX G30 Handle Grip Fixing Ring

01.12.4960.00; Ninebot MAX G30 Inner Hexagon Flat End Screw _M5*16

04.01.0286.00; Ninebot MAX G30 Open Holding Ring

04.06.0056.00; Ninebot MAX G30 Dust Cover Assembly

04.04.0044.00; Ninebot MAX G30 Adjustment Nut_M5*16

04.04.0045.00; Ninebot MAX G30 Lock Cylinder

04.06.0055.00; Ninebot MAX G30 Dust Cover

04.01.0285.00; Ninebot MAX G30 Stem Waterproof Plug

04.01.0275.00; Ninebot MAX G30 Charging Port Waterproof Ring

04.01.0281.00; Ninebot MAX G30 Charging Base Cover Waterproof Rubber Plug

SCOOTERHACKING.ORG